BASIC CONFIGURATION

SUBASH SUBEDI

## 1. Bridge Port Configuration

- Step 1: Select "Bridge" On that, you will find the "Bridge" option.
- Step 2: Click on the "add" symbol "+".
- Step 3: In "Name" if you want to change the name, then change; otherwise, leave it.
- Step 4: Now we will not change anything; select "Apply" & "OK"
- Step 5: Select "Bridge" On that you will find the "Ports" option.
- Step 6: Click on the "add" symbol "+".
- Step 7: In "Interface" select the "ethernet" port, & In "Bridge" select the name of bridge In step 3, you have create.
- Step 8: Select "Apply" & "OK" Same process step for other Ethernet port also.

#### **CMD**

/interface bridge add name=[Name of bridge port]

interface bridge port add bridge=[Name of bridge port] interface=ether[ether port]

interface bridge port print brief

#### **EXAMPLE**

interface bridge add name=bridge1

interface bridge port add bridge=bridge1 interface=ether2

interface bridge port add bridge=bridge1 interface=ether3

interface bridge port add bridge=bridge1 interface=ether4

interface bridge port add bridge=bridge1 interface=ether5 interface bridge port add bridge=bridge1 interface=ether6 interface bridge port add bridge=bridge1 interface=ether7 interface bridge port add bridge=bridge1 interface=ether8 interface bridge port add bridge=bridge1 interface=ether9 interface bridge port print brief




Figure 1

# 2. IP Address Assign

- Step 1: Select "IP" On that you will find the "Addresses" option.
- Step 2: Click on the "add" symbol "+".
- Step 3: In "Address" enter the public IP & In "Network" enter the gateways of that IP.
- Step 4: In "Interface" select which interface you want to assign.
- Step 5: Select "Apply" & "OK".
- Step 2: Click on the "add" symbol "+".
- Step 6: In "Address" enter the local IP & In "Network" enter the gateways of that IP.
- Step 7: In "Interface" select which interface you want to assign. For now, name of bridge
- Step 8: Select "Apply" & "OK"

#### **CMD**

```
ip address/
add address=[Public Ip ] interface=[name of ethernet]
add address=[local ip range] interface=[name of bridge interface]
```

#### **EXAMPLE**

```
ip address/
add address=10.10.69.50/24 interface=ether1
add address=192.168.1.1/24 interface=ether1
```




Figure 2

# 3. DNS Assign

Step 1: Select "IP" On that you will find the "DNS" option.

Step 2: In "Servers" enter the DNS of your ISP.

Step 3: Select "Apply" & "OK"

#### **CMD**

ip dns/

set servers=[Enter your ISP DNS]

### **Example**

ip dns/

set servers=8.8.8.8




Figure 3

## 4. DHCP Configuration

- Step 1: Select "IP" On that you will find the "DHCP SERVER" option.
- Step 2: In "DHCP" there you will find "DHCP Setup" Click on that option. Then a popup setup will come.
- Step 3: In "DHCP Server Interface" Select the bridge name in 1 you have created and "Next".
- Step 4: In "DHCP Address Space" insert the local IP and their subnet as required, or it will come automatically and "Next".
- Step 5: In "Gateway for DHCP Network" provide the local IP gateways, or it will come automatically and "Next".
- Step 6: In the "Addresses to Give Out" range of IP addresses, or it will come automatically and "Next".
- Step 7: In "DNS Servers" enter the ISP DNS that we have given Google for now; it will come automatically and "Next".
- Step 8: In "Lease Time" set as default and click "Next"

#### **CMD**

ip pool add name=[Name of DHCP Pool] ranges=[Range of local ip]

ip dhcp-server add name=[Name of dhcp server] interface=[Assign Interface] address-pool=[Name of DHCP Pool] disabled=no

ip dhcp-server network add address=[Local Ip Address with subnet] gateway=[gateway of local IP] dns-server=[DNS of ISP]

ip dhcp-server enable [Name of dhcp server]

#### **EXAMPLE**

ip pool add name=dhcp pool ranges=192.168.1.2-192.168.1.254

ip dhcp-server add name=dhcp1 interface=bridge1 address-pool=dhcp pool disabled=no

ip dhcp-server network add address=192.168.1.0/24 gateway=192.1.68.1.1 dns-server=8.8.8.8,8.8.4.4

ip dhcp-server enable dhcp1

ip dhcp-server/print

ip dhcp-server lease print





Figure 4



# 5. Configure the route

Step 1: Select "IP" On that you will find the "Routes" option.

Step 2: Click on the "add" symbol "+".

Step 3: In "Dst. Address" Enter "0.0.0.0/0" & In "Gateway" Public IP that is provided by ISP

Step 4: Select "Apply" & "OK"

#### **CMD**

/ip route add dst-address=0.0.0.0/0 gateway=[Public Ip]

## Example

/ip route add dst-address=0.0.0.0/0 gateway=10.10.69.250




Figure 13

# 6. Set up NAT

Step 1: Select "IP" On that you will find the "Routes" Option.

Step 2: Click on the "add" symbol "+".

Step 3: In "General" you will find "Chain" leave it default "srcnat"

Step 4: Select "Action" you will find "Action" in that select "masquerade"

Step 5: Select "Apply" & "OK"

#### **CMD**

ip firewall nat/

add chain=srcnat action=masquerade

## **Example**

ip firewall nat/

add chain=srcnat action=masquerade




Figure 14

#### **FINISHED**

NOW CONNECTED TO YOUR PC and Internet connection will arrive.